



نحوه نگهداری و تمیز کردن شیشه/فیلم هوشمند

ISG smart glass/film maintenance manual

۱. فیلم یا شیشه های هوشمند میبایست حتما ۴ ساعت طی ۲۴ ساعت در حالت خاموش (کدر) باشند.
۲. به منظور حفظ کیفیت عملکرد، شیشه های هوشمند نباید برای مدت زمان طولانی در حالت خاموش باشند و بهتر است حتما هر چند وقت یکبار روشن و خاموش شوند.
۳. برای تمیز کردن شیشه های هوشمند ابتدا میبایست آن را در حالت خاموش (کدر) قرار دهید.
۴. تا خشک شدن کامل شیشه های هوشمند، آن ها را روشن نکنید.
۵. هنگام تمیز کردن دقت کنید آسیبی به اتصالات برقی شیشه هوشمند وارد نشود.
۶. از ورود آب به داخل پروفیل جدا پرهیز کنید.
۷. از پارچه بدون پرز میکروفایبر با کیفیت بالا برای تمیز کردن شیشه های هوشمند استفاده کنید.
۸. به هیچ عنوان از مواد شوینده و یا آب بیش از اندازه برای تمیز کردن شیشه یا فیلم های هوشمند استفاده نکنید.

1. ISG Smart glass/film must be switched OFF (opaque mode) for a minimum of 4 hours every 24 hours.
2. In order to ensure correct functionality of ISG smart glass/film, it is recommended that the smart panels be switched ON and OFF regularly.
3. Always power off smart glass/film when cleaning.
4. Do not power on Smart glass/film until 100% becomes dry.
5. Be careful not to disturb any electrical connections.
6. Avoid any liquid from entering framework.
7. Use only a clean lint free microfiber cloth to clean.
8. Avoid the use of harsh chemical and excessive water.